



We are always ready to answer any questions
on our customer support hotline
+45 42 45 44 00, and you are also
welcome to email us at
info@designers-first.com.

Thank you for choosing DESIGNERS FIRST.

Installation instructions

Congratulation on your new EDGE.

Please familiarize yourself with this set of installation
and care instructions before using the product.



EDGE
by Sabine Appel

Installation:

In addition to the included hardware and tools, you will also need a power drill, 8 mm (5/16") drill bit, and a level.

Important

Your new EDGE shelf is strong and can, without any problems, carry a load of 10 kg (22 lb). However, if all the load is at the shelf's extremes, there could be insignificant bending.

We recommend installing the EDGE shelf using the included screw anchors. Drill 8 mm (5/16") holes to about 4 cm (1³⁷/₆₄") deep, and taking care not to mount in the cement if installing on a brick wall.

Please note that brick walls seldom are perfectly plumb. It is a challenge to getting the shelf 100% perpendicular to the wall.

Use the included self-drilling screws to install directly into wood.

Drywall installation requires specialized hardware not included with the EDGE.

Accessory:

The unique oak EDGE TRAY is an excellent accessory to the EDGE shelf and is available in our webshop.

Cleaning and care of EDGE TRAY in oak:

Daily cleaning

Use a moist cloth to wipe down the surface. Do NOT use any cleaning solvents or chemicals.

Maintenance

Treat the EDGE TRAY as needed with wood or teak oils multiple times per year to keep it clean from filth and fluids.

